

DELAY BOX WIRING

(10 SECOND DELAY)

TERMINAL

85 VEHICLE GROUND

86 12V+ FUSED TO IGNITION ON

30 LOCK UP SOLENOID (+)

#87 CONNECT TO 4TH GEAR PRESSURE SWITCH. DELAY WILL START WHEN GROUNDED IN 4TH GEAR.

OR

OPTIONAL—12V+ WILL START DELAY ON A TOGGLE SWITCH.

Wiring Diagram

